

How to import the Synergy IR Display Database into the Synergy software.

Go to the “Synergy” page or the “Software Configuration page” on the iKON AVS web site

On the Synergy page select the “Downloads” tab


Click on the “Synergy IR Display Database.IXL” link and save this file onto your computer.

Open the Synergy Editor Software.

Click on the “Edit IR Displays” button 

A window will open called “IR display selector”



Within this window click on the Import button 

A window will open where you can search your computer for the saved “Synergy IR Display Database.IXL”



Navigate to the saved “Synergy IR Display Database.IXL” and click on the open button 

The IR Display Database will now be imported for use into the Synergy software